

Kodo RV-9 Robot Vacuum - Quick Start

1. Place the charging dock against a wall with 0.5 m free on each side and 1.5 m in front.
2. Charge the robot fully before the first run (about 4 hours).
3. Install the Kodo Home app and add the robot over 2.4 GHz Wi-Fi. 5 GHz networks are not supported.
4. The first run builds a map of your home. Open all doors and pick up cables and socks.
5. In the app you can draw no-go zones, for example around the dog bowl.

Maintenance

Empty the dust bin after every run. Clean the main brush every week and replace it every 6 to 12 months. Replace the filter every 3 months.

Status lights and errors

Blinking red with error 2: the main brush is stuck; remove hair and threads. Error 5: the bumper is stuck. Error 8: the robot cannot find the dock.

Warranty

12 months on the robot, 6 months on the battery.